

Keys & Cylinders



Master

Cylinder

(KC-SM-NK-XXX)



- Identified with a letter "M" Stamped on the scalp
- Used in any lock were "Mastered" functionality is required/preferred
- The Green Master Key will operate any of these cylinders
- This cylinder should NEVER to be installed in an entrance lock deadbolt (This would compromise the safety of the unit owner as the Green master key will operate this cylinder)

NON-Master

Cylinder

(KC-SNM-NK-XXX)



- Identified by it's blank silver scalp
- The only keys that will operate a "Non-Mastered" cylinder are the purple or gray keys with the same key number assigned to it
- Used in any lock where "NON-Mastered" functionality is required/preferred
- This cylinder should always be installed in the entrance lock deadbolt core (for the security of the end user)

User Key

(KEY-GXXX)



- The user key is identified by it's purple colored key fob
- Keys numbers range from G301-G390
- The key number is etched in to the metal under purple fob
- This key will operate all locks on a "Keyed Alike" unit
- The User key will operate all cylinders (Mastered and Non Mastered) that have the same key number assigned to it

G391 Key

(KEY-G391)



- The G391 key is identified by its gray key fob
- The G391 key is a generic user key used in standard compartment area locks such as baggage/slam locks, cam locks and bar locks
- The intended purpose of this key is for dealerships to easily change the Gray G391 key to match the units purple key used on its entrance door
To learn more about the "Dealer Pass Through" program please visit <http://www.rvlocksandmore.com/LocksKeys/G391>

Master Key

(KEY-MASTER)



- Identified by it's Green Key Fob Labeled "MK9901"
- This key will operate all "Mastered" cylinders (with an "M" on the scalp) on the unit
- Intended for dealerships and transporters to show/transport units (This allows for use of the single master key to access units rather than needing a key ring with all 90 Global Link keys)
- The master key will not operate any "NON-Mastered" cylinder
- For security puposes this key is NOT for resale

Change Key

"Tool"

(KEY-CHANGE)



- Identified by it's Yellow Key Fob labeled "Tool"
- This key is NOT for resale
- This key will not operate any cylinder installed in Global Link Locks
- This key will remove/install Global Link cylinders in locks as long as cylinders are in correct position to be removed
(See separate Keyed Alike Instructions)